JACKOBOARD®

Sealing set 2-k





Fields of application

For sealing the joints on JACKOBOARD® Plano construction boards and/or JACKOBOARD® Aqua shower elements when combined with ceramic tiles in wet rooms, showers and the like.

Application

Before use, please read the safety recommendations on the label. Application temperature: +5°C to +20°C

Mix both components in a clean container until you have a homogeneous consistency that is free of lumps and suitable for application. The mixing proportions of the components are already correct. Using a firm brush or palette knife, apply the product thickly and to the entire surface of all butt joints of JACKOBOARD® Plano construction boards and/or JACKOBOARD® Aqua shower elements that require sealing.

Apply the sealant over the width of the sealing tape +1 cm overlap. The sealant is sufficient for around 10 m. Use mixed material within half an hour. Do not add water or liquid components to try and revive sealant that has already started to harden.

In corners, start by installing the sealing corners in the sealant without creases. Then cover the top edge of the sealing corners with sealant before positioning the sealing tape centrally over the joints to be sealed and fixing it in place smoothly and without creases. When positioning the sealing tape on the sealing corners, allow a butt joint overlap of around 50 mm.

Then apply a second layer to the sealing tape. After 4 hours, ceramic tiles can be applied on the sealant using thin bed mortar.

Please note

The information provided in this leaflet is based on our knowledge and experience to date. It does not constitute a guarantee in any legal sense. When using this product, please always bear in mind the circumstances of the particular intended application, especially with regard to physical, technical and legal construction issues.



