



JACKBOARD® Sabo Assembly Set

Set for cladding WC wall elements.




JACKOBOARD® Sabo Assembly Set is designed for universal application in cladding WC wall elements. It can be used to clad from wall to wall, as shown in this example, or for cladding a box shape.

- 1)** The JACKOBOARD® Sabo assembly mounting board is first of all shortened to the right size.







- 2)** The JACKOBOARD® Sabo assembly mounting board is screwed onto the steel frame of the WC wall element. It is fastened with self-tapping screws (countersunk head with fine thread) and JACKOBOARD® insulation board discs with Ø 36 mm. The JACKOBOARD® Sabo Assembly Set contains the right screws and insulation board discs (10 of each). The holes may need to be drilled. The fasteners described above can also be used for metal studwork. To fasten to wood studwork use standard dry-wall screws with a coarse thread and the JACKOBOARD® insulation board discs with Ø 36 mm.

- 3)** Cut the front panel out of the 2nd board and then the cutout for the flush plate.




Bolt the front panel into place.





4) After cutting, the cover is bonded with a suitable assembly adhesive (e.g. JACKODUR® assembly adhesive, BOARD-FIX®).



5) Seal all joints and edges with glass fibre tape (e.g. JACKOBOARD® glass fibre tape).



6) JACKOBOARD® Sabo Assembly Set must be covered with tiles to ensure the sufficiently even distribution of pressure when the WC is in use. The tiles can be laid directly on JACKOBOARD® Sabo Assembly Set. All types and sizes of tiles can be used in principle. The tiles should, however, measure at least 100 x 100 mm, and be at least 7 mm thick. Once the tile adhesive has hardened, the WC can be mounted on the tile surface.

Notes: JACKOBOARD® Sabo Assembly Set is only a cladding element. The load of the WC must therefore always be transferred through the steel frame of the WC wall element. With WCs that have a reduced contact surface, such as Subway 2.0 from Villeroy & Boch or WCs of a similar design, pre-wall elements for WCs, which have additional struts running vertically underneath the contact surfaces of the WC, must be used.

JACKON Insulation GmbH

Carl-Benz-Straße 8
D-33803 Steinhagen

T +49 (0) 5204 9955 - 0

F +49 (0) 5204 9955 - 400

E info@jackodur.com

W www.jackon-insulation.com

Please note

The information in this leaflet is based on our experience and current materials specification. It represents no specific guarantee and the instructions for use outlined should be always observed together with considerations regarding building structure and existing Building Law.