
JACKOBOARD® Sabo

Assembly mounting board for cladding WC wall elements.







Installation Instructions


JACKOBOARD[®] Sabo is designed for universal application in cladding WC wall elements. It can be used to clad from wall to wall, as shown in this example, or for cladding a box shape.

1) First, cut JACKOBOARD[®] Sabo to the right size.






2) JACKOBOARD[®] Sabo is screwed onto the steel frame of the WC wall element. It is fastened with self-tapping screws (countersunk head with fine thread) and JACKOBOARD[®] insulation board discs with Ø 36 mm. We recommend the JACKOBOARD[®] Sabo accessories for this. The fasteners described above can also be used for metal studwork. To fasten to wood studwork use standard dry-wall screws with a coarse thread and the JACKOBOARD[®] insulation board discs with Ø 36 mm.







3) After cutting, the cover is bonded with a suitable assembly adhesive (e.g. JACKODUR[®] assembly adhesive, BOARD-FIX[®]).

4) All edges are filled with a suitable glass fibre tape (e.g. JACKOBOARD[®] glass fibre tape).



5) JACKOBOARD[®] Sabo must be covered with tiles to ensure the sufficiently even distribution of pressure when the WC is in use. The tiles can be laid directly on JACKOBOARD[®] Sabo. All types and sizes of tiles can be used in principle. The tiles should, however, measure at least 100 x 100 mm, and be at least 7 mm thick. Once the tile adhesive has hardened, the WC can be mounted on the tile surface.

Note: JACKOBOARD[®] Sabo is only designed for cladding purposes. The load of the WC must therefore always be transferred through the steel frame of the WC wall element. With WCs that have a reduced contact surface, such as Subway 2.0 from Villeroy & Boch or WCs of a similar design, pre-wall elements for WCs, which have additional struts running vertically underneath the contact surfaces of the WC, must be used.

JACKOBOARD®



JACKON Insulation GmbH

Carl-Benz-Straße 8 D-33803 Steinhagen

- Т +49 (0) 5204 9955 - 0 F +49 (0) 5204 9955 - 400
- E info@jackodur.com
- W www.jackon-insulation.com

Please note

The information in this leaflet is based on our experience and current materials specification. It represents no specific guarantee and the instructions for use outlined should be always observed together with considerations regarding building structure and existing Building Law.